






TCP Smart Heating Schedules




From the homepage go to the SMART menu




Start a smart automation using the + icon top right




Choose SCHEDULE from the list




Select the time you wish the schedule to start




Click REPEAT and then tick the days you want the schedule to run on




Click NEXT




Choose RUN THE DEVICE from the smart automation list




Select your radiator




Select SWITCH from the function list to turn the heater on




Make sure ON is selected




To set the target temperature choose TARGET TEMPERATURE from the function list



Set the desired temperature you wish the radiator to reach



Name the Schedule and save to finish



The Schedule will now be in the Smart Automation list. You can make any number of different schedules by repeating the steps above